

## High dynamic eccentricity type (code E)

- a. For high static and dynamic eccentricities.
- b. For high frequency oscillations.



TBE



SME



SCE



SAE

# FOS